

DRAG2ZERO

44 Sram AXS Wire- less Grip



1. Loosen 2 M3 button head bolts
and place SRAM Wireless AXS blip
into grip



2. Place top cover down onto grip



3. Finger tighten bolts